

	FRACTIONAL (US) (AUS)			4	4½	5	5½	6	6½	7	7½	8	8½	9	9½	10	10½	11-14
	STRAIGHT (UK)	1	1½	2	2½	3	3½	4	4½	5	5½	6	6½	7	7½	8	8½	9
	EUROPEAN	32	33½	34	34½	35	35½	36	36½	37	37½	38	39	40	41	42	43	44
STYLE NUMBER	DESCRIPTION																	
S0105 - S0139	POINTES/DEMIS		1½	2	2½	2½-3	3-3½	3½-4	4-4½	4½-5	5-5½	5½-6	6	Depending on width - approx. size only				
S0201 / S0211 / S0231	PROLITE I		1-1½	1½-2	2-2½	2½-3	3	3-3½	3½-4	4-4½	4½-5	5-5½	5½-6	6-6½	6½-7	7½	8	
S0213 / S0208	PROLITE II		1-1½	1½-2	2-2½	2½-3	3	3-3½	3½-4	4-4½	4½-5	5-5½	5½-6	6-6½	6½-7	7½	8	
S0205	DANSOFT		1	1½	2	2½	3	3-3½	3½-4	4-4½	4½-5	5-5½	5½-6	6-6½	6½-7			
S0302L / S0305L	TAP-ON RHYTHM	4	4½	5	5½	6	6½	7	7½	8	8½	9	9½	10	10½	11	11½	12
S0320L / S0323	SHOWCASE / SHOWTAPPER		4	4½	5	5½	6	6½	7	7½	8	8½	9	9½	10	10½	11	
S0303	SHOWSTOPPER			2	2½	3	3½	4	4½	5	5½	6	6½	7	7½	8	8½	9
S0304L	CURTAIN CALL		4	4½	5	5½	6	6½	7	7½	8	8½	9	9½	10	10½	11	11½-12
S0306	CABARET		4	4½	5	5½	6	6½	7	7½	8	8½	9	9½	10	10½	11	11½-12
S0307	CHORUS			4	4½	5	5½	6	6½	7	7½	8	8½	9	9½	10		
S0300L / S0301L	JAZZ TAP/TIME		4	4½	5	5½	6	6½	7	7½	8	8½	9	9½	10	10½	11	
S0388L	TAP-FLEX		4	4½	5	5½	6	6½	7	7½	8	8½	9	9½	10	10½	11	11½-12
S0314L / S0315L	KARACTA		4	4½	5	5½	6	6½	7	7½	8	8½	9	9½	10	10½	11	11½-12
S0402L	JAZZ LITE		4	4½	5	5½	6	6½	7	7½	8	8½	9	9½	10	10½	11	11½-12
S0403L	ULTRA FLEX		4	4½	5	5½	6	6½	7	7½	8	8½	9	9½	10			
S0473L	ULTRA FLEX II			4	4½	5	5½	6	6½	7	7½	8	8½	9	9½	10	10½	11-13
S0480L	ENDUROTECH			4	4½	5	5½	6	6½	7	7½	8	8½	9	9½	10	10½	11-14
S0493L	NEO-JAZZ		4½	5	5½	6	6½	7	7½	8	8½	9	9½	10				
S0499L	ELASTA BOOT			4	4½	5	5½	6	6½	7	7½	8	8½	9	9½	10	10½	11-14
S0500	JAZZ SNEAKER	4	4½	5	5½	6	6½	7	7½	8	8½	9	9½	10	10½	11	11½	12-14
S0508	BOOST		4	4½	5	5½	6	6½	7	7½	8	8½	9	9½	10	10½	11	11½-14
S0538L	CLASSIC BOOST		4	4½	5	5½	6	6½	7	7½	8	8½	9	9½	10	10½	11	11½-14
S0539	BOOST MESH	4	4½	5	5½	6	6½	7	7½	8	8½	9	9½	10	10½	11	11½	12-14
S0540	BOOST SLIP-ON (TOGGLE)	4	4½	5	5½	6	6½	7	7½	8	8½	9	9½	10	10½	11	11½	12-14
S0555	BOOST NEW SLIP-ON			4	4½	5	5½	6	6½	7	7½	8	8½	9	9½	10		
S0575	STEALTH			4	4½	5	5½	6	6½	7	7½	8	8½	9	9½	10	10½	11
S0407 / S0427	GRECIAN SANDAL / PARIS			4	4½	5	5½	6	6½	7	7½	8	8½	9	9½	10		
S0410	CELTIC FLING			2	2-2½	2½-3	3-3½	3½	4	4½	5	5½	6	6½	7			
S0613L	JETS	28-33	34		35		36		37		38	39	40	41	42	43	44	45-46
S0702L / S0732L	BRIDAL			4	4½	5	5½	6	6½	7	7½	8	8½	9	9½	10		
S0300 / S0301	JAZZ TAP/TIME	BOYS					YOUTHS							MENS				
		9-13	13½	1	1½	2	2½	3	3½	4	4½	5	5½	6-6½	7-7½	8-8½	9-9½	10-12